

***POWERline***

**2235**

ADJUSTMENT MANUAL

This Adjustment Manual is valid for machines  
from the following serial numbers onwards:

# 7 205 458 →

The reprinting, copying or translation of PFAFF Service Manuals, whether in whole or in part, is only permitted with our previous authorization and with written reference to the source.

**PFAFF Industriesysteme  
und Maschinen AG**

Hans-Geiger-Str. 12 - IG Nord  
D-67661 Kaiserslautern

	Contents .....	Page
<b>1</b>	<b>Adjustment .....</b>	<b>4</b>
1.01	Notes on adjustment .....	4
1.02	Tools, gauges and other accessories for adjusting .....	4
1.03	Abbreviations .....	4
1.04	Explanation of the symbols.....	4
1.05	Adjusting the basic machine .....	5
1.05.01	Basic position of the balance wheel (adjustment aid).....	5
1.05.02	Balance weight .....	6
1.05.03	Zero position of the unison feed .....	7
1.05.04	Feeding motion of the unison feed .....	8
1.05.05	Lifting motion of the bottom feed dog .....	9
1.05.06	Height of the bottom feed dog .....	11
1.05.07	Feeding stroke difference .....	12
1.05.08	Preliminary adjustment of the needle height.....	13
1.05.09	Needle rise, hook clearance and needle height .....	14
1.05.10	Top feed stroke .....	15
1.05.11	Top-feed lifting motion .....	16
1.05.12	Adjusting the potentiometer for speed reduction(only on the 2235 PREMIUM) .....	17
1.05.13	Bobbin winder.....	18
1.05.14	Thread check spring and thread regulator .....	19
1.05.15	Sewing foot pressure.....	20
1.05.16	Lubrication .....	21
1.05.17	Limiting the stitch length .....	22
1.06	Adjusting the thread trimmer -900/91.....	23
1.06.01	Basic position of the thread trimmer .....	23
1.06.02	Control cam to roller lever clearance (resting position).....	24
1.06.03	Adjusting the control cam .....	25
1.06.04	Knife pressure.....	26
1.06.05	Manual cutting test .....	27
<b>2</b>	<b>Block diagram .....</b>	<b>28</b>
2.01	PFAFF 2235 PLUS with AB 321 .....	28
2.02	PFAFF 2235 PREMIUM with PF 321 .....	29

## 1 Adjustment



Please observe all notes from Chapter 1 **Safety** of the instruction manual!  
In particular care must be taken to see that all protective devices are refitted properly after adjustment, see Chapter 1.06 **Danger warnings** of the instruction manual!



If not otherwise stated, the machine must be disconnected from the electrical power supply. Danger of injury due to unintentional starting of the machine!

### 1.01 Notes on adjustment

All following adjustments are based on a fully assembled machine and may only be carried out by expert staff trained for this purpose.

Machine covers, which have to be removed and replaced to carry out checks and adjustments, are not mentioned in the text.

The order of the following chapters corresponds to the most logical work sequence for machines which have to be completely adjusted. If only specific individual work steps are carried out, both the preceding and following chapters must be observed.

Screws, nuts indicated in brackets ( ) are fastenings for machine parts, which must be loosened before adjustment and tightened again afterwards.

### 1.02 Tools, gauges and other accessories for adjusting

- Screwdrivers with blade width from 2 to 10 mm
- Spanners (wrenches) with jaw width from 7 to 14 mm
- 1 set Allen keys from 1.5 to 6 mm
- 1 gauge for the top feed stroke 5.0 mm (Part No. 61-111 633-60)
- 1 feed dog adjustment gauge, Part No. 61-111 689-04
- Metal rule (part No. 08-880 218-00)
- Sewing thread and test materials

### 1.03 Abbreviations

t.d.c. = top dead centre


b.d.c. = bottom dead centre

### 1.04 Explanation of the symbols

In this adjustment manual, symbols emphasize operations to be carried out or important information. The symbols used have the following meaning:



Note, information



Service, repair, adjustment, maintenance  
(work to be carried out by qualified staff only)





# Adjustment

## 1.05.02 Balance weight

### Requirement

When the needle bar is positioned at b.d.c. (balance wheel position 180°) the largest eccentricity of the balance weight 1 should be at the top.




- Adjust balance weight 1 (screw 2) in accordance with the requirement.

## 1.05.03 Zero position of the unison feed

### Requirement

When the stitch length is set at "0", the top and bottom feed dogs and the needle bar should not make any feeding motion when the balance wheel is turned.





- Remove spring 1.
- Adjust crank 2 (screw 3) in accordance with the **requirement**.
- Replace the spring 1.

## 1.05.04 Feeding motion of the unison feed

### Requirement

When the needle bar is positioned at b.d.c. (balance wheel position  $180^\circ$ ), and the maximum stitch length is set, the top and bottom feed dogs and the needle bar should not make any feeding motion when the reverse-feed lever is pressed.





- Adjust eccentric 1 (screws 2) in accordance with the requirement. Make sure that the cut-out (see arrow) is visible.



## 1.05.05 Lifting motion of the bottom feed dog

### Requirement

When the balance wheel is positioned at  $180^\circ$ , the feed dog should be at t.d.c.



- Adjust eccentric 1 (screws 2) in accordance with the **requirement**.



Use the kit with the Order No. 91-501 398-90 to deactivate the transporter lifting movement.

### Install assembly and adjust

- Remove collar 3 (screws 4) and crank 5 (screw 6, safety ring 7).
- Mount the preassembled parts of the kit as shown in figures 1 - 05a.
- Adjust bottom transporter height and stroke movement where required.





Fig. 1 - 05a



### Activate lifting movement

- Lifting movement is activated if connection part **8** is swiveled in as shown in figures 1 - 05a, and screws **9** (M6 x 16) and **10** (M5 x 16) have been attached.



### Deactivate lifting movement

- Remove screws **9** and **10** and swivel connection part **8** (screw **11**) towards the right.
- Replace screw **9** with a screw M6 x 25.
- Replace screw **10** with a threaded pin M5 x 25 and tighten to stop.

## 1.05.06 Height of the bottom feed dog

### Requirement

1. When the stitch length is set at "0" and the needle bar is positioned at b.d.c. (balance wheel position 180°), the bottom feed dog should be positioned 0.5 mm horizontally above the top edge of the needle plate.
2. In the direction of sewing, the bottom feed dog should be positioned in the centre of the needle plate slot.





- Turn lifting crank 1 (screws 2) and eccentric sleeve 3 (screws 4) in accordance with requirement 1.
- Adjust feed bar 5 (screws 4) in accordance with requirement 2.

# Adjustment

## 1.05.07 Feeding stroke difference

### Requirement

With the maximum stitch length set, when the balance wheel is turned the feeding strokes of the needle and the bottom feed dog should be the same.



- With connecting rod 1 (nut 2) increase ("+") or reduce (-) the needle feed stroke in accordance with the **requirement**.

## 1.05.08 Preliminary adjustment of the needle height

### Requirement

When the needle bar is positioned at t.d.c. (balance wheel position 0°), the clearance between the needle point and the needle plate should be 22 mm.





Fig. 1 - 08



- Without turning it, re-position needle bar 1 (screw 2) in accordance with the requirement.



Make sure that needle bar 1 and foot 3 do not collide.

## 1.05.09 Needle rise, hook clearance and needle height

### Requirement

With the stitch length set at "4.5" and in the needle rise position (see table)

1. The hook point **5** should be positioned at "needle centre" with a hook-to-needle clearance of **0.05 – 0.10 mm**.
2. The top of the needle eye should be positioned **0.8 mm** below hook point **5**.



### Needle rise position

Model C: Balance wheel position **202° / 2.0 mm**

Model C/D: Balance wheel position **204° / 2.4 mm**





Fig. 1 - 09



- Set stitch length "4.5" and bring the balance wheel into the needle rise position.
- Adjust hook **1** (screws **2**) in accordance with **requirement 1**.
- Bring oil distributor ring **3** (screw **4**) into contact with hook **1**.
- Without turning it, re-position the needle bar in accordance with the **requirement 2**.

## 1.05.10 Top feed stroke

**Requirement**

With adjustment wheel 1 set at "5", the top feed dog 7 and presser foot 4 should each rise by 5.0 mm.





Fig. 1 - 10





- Remove the bottom feed dog and set adjustment wheel 1 at "5".
- Loosen the screws of the needle plate, place the metal gauge over the opening of the needle plate slot so that both sewing feet can be lowered onto the metal gauge.
- For the preliminary adjustment, adjust crank 2 (screw 3) so that there is a clearance of 5 mm between presser foot 4 and the needle plate.
- Adjust crank 5 (screw 6) so that top feed dog 7 and presser foot 4 have the same stroke.
- Check the adjustment in accordance with the **requirement**, and correct if necessary.

# Adjustment

## 1.05.11 Top-feed lifting motion

### Requirement

The top feed dog should just have reached the needle plate when the presser foot lift is set at **5 mm** and the needle descending from above is **2 mm** above the needle plate.



- Turn eccentric 1 (screw 2) in accordance with the requirement.



- 1.05.12     Adjusting the potentiometer for speed reduction(only on the 2235 PREMIUM)
- Press "P" on the control panel, while simultaneously switching the machine on.
  - Enter the code **3112** via the numbered keys and confirm by pressing "E".
  - Select parameter **501** via the numbered keys and confirm by pressing "E".
  - Set the smallest stroke "0".
  - Using the stroke adjustment function, call up the small stroke (LED off), see instruction manual.
  - Take over the value displayed under parameter **501** by pressing "+".
  - Select parameter **502** via the numbered keys.
  - Set the largest stroke "0".
  - Using the stroke adjustment function, call up the large stroke (LED on).
  - Take over the value displayed under parameter **502** by pressing "+".
  - Press "P" twice to quit the input level
  - The new values are taken over when sewing is started, and these are maintained even after the machine is switched off.





The speed is adjusted in accordance with Chapter **3.03 Maximum Speed** in the instruction manual.

Under parameter **117** the speed at max. stroke adjustment can be reduced again.

## 1.05.13 Bobbin winder

### Requirement

1. When the bobbin winder is engaged, the winding spindle must be driven reliably.  
When it is disengaged, friction wheel **3** should not be touching drive wheel **1**.
2. When it is switched off, the bobbin winder must click securely into its end position (knife raised).





- Adjust drive wheel **1** (screw **2**) in accordance with the **requirement**.

## 1.05.14 Thread check spring and thread regulator

### Requirement

1. The movement of thread regulator **3** must be completed when the needle point enters the material.
2. When the thread loop is at its largest while being passed around the hook, the check thread spring **3** should rise slightly from the rest **1**.



- Position rest **1** (screw **2**) in accordance with **requirement 1**.
- Turn sleeve **4** (screw **2**) to adjust the tension of thread check spring **3**.
- Position thread regulator **5** (screw **6**) in accordance with **requirement 2**.



For technical reasons it may be necessary to deviate from the indicated spring stroke or spring tension.



Move thread regulator **5** (screw **6**) towards ("**+**") (= more thread) or ("**-**") (= less thread).

# Adjustment

## 1.05.15 Sewing foot pressure

### Requirement

The material should be fed properly even at maximum speed and with the smallest stroke.





- Turn adjustment wheel 1 in accordance with the requirement.

## 1.05.16 Lubrication

### Requirement

After a running time of **10** seconds a thin film of oil should be visible on paper strip **1** when this is held over the hook.



- Check that the machine is filled with oil and that the oil lines are free of air.
- Run the machine for **2 – 3 min.**





Do not put your hands into the needle area when the machine is running!  
 Danger of injury from moving parts!

- With the machine running, hold paper strip **1** against the hook and check the **requirement**.
- If necessary, regulate amount of oil with screw **2**.

## 1.05.17 Limiting the stitch length



When exchanging the parts kit with stitch lengths differing from the as-delivered state of the machine, limit the max. stitch length using stitch adjuster 4.





- Set the desired max. stitch length at control button 1 (on model CN = 6.0 mm, on model CN9 + C/DN9 = 9 mm)
- Remove adjustment knob 1 (screws 2) and scale dial 3.
- Remove adjustment unit 4 (screws 5).
- Bring lineal 6 (screw 7) to the unit using stitch adjuster 4 (see arrow).
- Replace adjustment unit 4, scale dial 3 and adjustment knob 1.

## 1.06 Adjusting the thread trimmer -900/91

### 1.06.01 Basic position of the thread trimmer

#### Requirement

1. When the thread trimmer is in its resting position (cylinder extended), the point of thread catcher **6** should be flush with the cutting edge of knife **7** (see arrow).
2. The roller lever **3** should have a clearance of **1 mm** to the connecting piece.





- Adjust thread trimmer **1** (screws **2**) in accordance with **requirement 1**.
- Adjust roller lever **3** (only screw **4**) in accordance with **requirement 2**.

# Adjustment

## 1.06.02 Control cam to roller lever clearance (resting position)

### Requirement

When the thread trimmer is in its resting position (balance wheel position  $270^\circ$ ) there should be a clearance of **0.1 mm** between the roller lever **5** and the outside edge of control cam **1**.





- Adjust control cam **1** (screw **2**) together with retaining collar **3** (screw **4**) in accordance with the **requirement**.



## 1.06.03 Adjusting the control cam

### Requirement

When the take-up lever is at the top of its stroke (balance wheel position 70°), the cutting operation should just have been completed.





- Adjust control cam 1 (screw 2) in accordance with the requirement.

# Adjustment

## 1.06.04 Knife pressure

### Requirement

The thread should be cut reliably at all times.





- Increase ("+") or reduce ("-") the knife pressure accordingly with screw 1.

## 1.06.05 Manual cutting test

**Requirement**

Both the needle and the bobbin thread should be cut neatly.




- Bring thread catcher 1 by hand to its front position.
- Take a double thread and place it into the catcher slot.
- Carry out a manual cutting test.
- If the thread is not cut in accordance with the **requirement**, adjust the knife pressure as described in Chapter 1.06.04 Knife pressure.




Consult the instruction manual for the drive for a description of the parameter settings and a list of the parameters.

# Block diagram

2 Block diagram  
 2.01 PFAFF 2235 PLUS with AB 321



2.02 PFAFF 2235 PREMIUM with PF 321





**Europäische Union**  
Wachstum durch Innovation – EFRE



## PFAFF Industriesysteme und Maschinen AG

Hans-Geiger-Str. 12 - IG Nord  
D-67661 Kaiserslautern

Phone: +49-6301 3205 - 0  
Fax: +49-6301 3205 1386  
E-mail: [info@pfaff-industrial.com](mailto:info@pfaff-industrial.com)

### Hotlines:

Technical service: +49-175/2243-101  
Application consultancy: +49-175/2243-102  
Spare-parts hotline: +49-175/2243-103

Printed in Germany