

# **EcoDrive**

**QE3760/QE5540**

**CE**

## **Type**

# **J50EDx**

## **Instruction Manual**

### **Part 2**

QUICK-ROTAN Elektromotoren GmbH  
Königstraße 154  
67655 Kaiserslautern  
Tel: 0631 / 200 38 80  
Fax: 0631 / 200 38 62  
E-Mail: [tech.supp@quick-rotan.com](mailto:tech.supp@quick-rotan.com)  
[www.quick-rotan.com](http://www.quick-rotan.com)

**English 2005-02-17**

## List of Contents Part 2

<b>Chapt.</b>	<b>Contents</b>	<b>Page</b>
<b>7.</b>	Description of the EcoDrive drive system	7.1 - 7.6
7.1	Motor QE3760 / QE5540	
7.2	Control system	
7.3	Speed control unit SWG2	
7.4	External operator panel EcoTop AQE	
7.5	Employment of the drive	
<b>8.</b>	Application	8.1 - 8.8
8.1	Sewing with the external operator's control panel EcoTop	
8.1.1	Sewing without sewing program (manual sewing)	
8.1.2	Sewing with sewing program (programmed sewing)	
8.1.3	Sewing programs	
8.1.4	Backtack / Darning programs	
8.2	Error messages (malfunction diagnostics)	
8.3	Bobbin thread monitoring	
<b>9.</b>	Programming by the user	9.1 - 9.12
9.1	User programming with operator panel EcoTop	
9.1.1	Direct programming	
9.1.1.1	Display of the lower display line	
9.1.1.2	Display of the upper display line	
9.1.1.3	Programming of the puller pressure and stitch length of the puller roller	
9.1.2	Parameter programming	
9.1.2.1	Programming level „a“ (operator level)	
9.1.2.2	Programming level „b“ (technician level)	
9.1.2.3	Programming level „c“ (special level)	
9.1.3	Reset	
<b>10.</b>	Start of operation	10.1 - 10.10
10.1	Control of the direction of rotation and of the reference position from the needle bar (needle position NPO)	
10.2	Learning procedure of the speed ratio	
10.3	Control of the needle positions NP1 / NP2	
10.4	Control of the maximum speed	
10.5	Hardware test	
10.6	Transfer of parameter and sewing program data with EcoTopoperator panel (quick configuration for multiple machines)	
10.6.1	Parameter transfer from EcoDrive to EcoTop	
10.6.2	Parameter transfer from EcoTop to EcoDrive	
10.6.3	Parameter and sewing program data transfer from EcoDrive to Q-Prog programming device	
10.6.4	Parameter and sewing program data transfer from Q-Prog programming device to EcoDrive	

**Technical updatings reserved!**

## 7. Description of the EcoDrive Drive System

The **EcoDrive** Drive System is an electronically commutated, brushless DC motor.

The system is composed of the following subassemblies




Fig. 7.1




Fig. 7.2




Fig. 7.3




Fig. 7.4

**Motor** QE3760 or QE5540 (**Fig.7.1**) with integrated optoelectronic incremental encoder for commutation and positioning.

**Control** (**Fig.7.2**) with

- mains connection with interference rejection circuit
- electronically controlled combinational circuit
- intermediate DC circuit
- motor-driven current inverter
- electronic control for motor control and machine specific functions
- connection for a sewing light

**Speed control unit** SWG2 (**Fig.7.3**)

**Control panel** (**Fig.7.4** - optional) EcoTop AQE for Lockstitch machines, EcoTop DQE for Chainstitch machines and EcoTop FQE for Overlock machines (see chap. 7.4, 7.5 and 7.6).

### 7.1 Motor QE3760

The motor is a synchronous motor. It has a permanent-magnetic rotor, a stator with three-phase winding and an optoelectronic increment encoder for commutation and positioning.

The rated capacity of the motor (shaft capacity) is 375W (QE3760), 550W (QE5540) in S5 mode.

The rated speed of the motor is 6000 rpm (QE3760), 4000 rpm (QE5540),

the maximum speed is 9000 rpm (QE3760), 4500 rpm (QE5540).

The motor has two mains leads:

- four-wire with special quadripolar AMP plug (X1) for connecting the stator coil to the control system
- six-wire shielded with nine-pole D-sub plug (X2) for connecting the increment encoder to the control system.

## 7.2 Control system




Fig. 7.5

8

Fig 7.6

The control box is attached to the underside of the machine table by means of the four enclosed screws.

The mains connection is single-phase, using the three-wire cord protruding from the rear and a standard safety plug.

### The control system has peripheral functions


on the front panel (Fig. 7.5):

**X0** nine-pole D-sub jack for data transfer

on the rear panel (Fig. 7.6):

#### sockets or connector plugs

- X1** quadripole socket for connecting the motor's stator coil
- X2** nine-pole D-sub jack for connecting the motor's increment encoder
- X3** nine-pole D-sub plug for connecting set point adjuster SWG2 (Art. No. 63.012)
- X4** nine-pole D-sub plug for connecting the control panel OC-TG/AP (Art. No. 64.175)
- X5** 37-pole D-sub jack for connecting the process control system (keys, switches, solenoids, solenoid valves) on the machine.
- X6** six-pole RJ45 western jack for connecting from a light barrier
- X7** six-pole RJ45 western jack for connecting from a bobbin thread monitor
- X8** nine-pole D-Sub-socket for the connection of the Puller/SRP



In function, the control is connected with the sewing machine/sewing unit via:

**Inputs (Ex)**, e.g. for push-buttons, switches, proximity switches, detectors

<799> =	1
<b>E1</b> (X5:5)	NHOS/TUM <394> = 0 / TUM <394> = 1 / NHOS <394> = 2 / NPW <394> = 3 / EST<394> = 4 / RIV <394> = 5 / RIUNT <394> = 6
<b>E2</b> (X5:6)	NHOS <446> = 1 / NPW <446> = 2 / EST <446> = 3 / EST <446> = 4 / RIV <446> = 5 / RIUNT <446> = 6 / UMSCH <446> = 7 / PULL <446> = 8

EST = Single stitch  
 NHOS = Needle up without thread trimming  
 NPW = Needle position change-over  
 PULL = Puller  
 RIUNT = Backtack suppression  
 RIV = Backtack inversion  
 START = Start  
 TUM = Feed reverse  
 UMSCH = Switch-over position

**Outputs (Ax)**, e.g. for solenoids, solenoid valves, signal indicators.

<799> =	1
<b>A1</b> (X5:37)	SN
<b>A3</b> (X5:27)	WI
<b>A4</b> (X5:35)	PF
<b>A5</b> (X5:34)	TUM

SN = Thread trimming  
 WI = Thread wiper  
 PF = Presserfoot up  
 TUM = Feed reverse

## 7.3 Encoder SWG2


the SWG2 is attached under the table with the provided bracket and mechanically connected with the pedal of the machine with the provided linkage.

Electrical connection of the SWG2 is made with the nin-pin coupling on plug X3 on the rear side of the control.


The SWG2 is an analog mechanical-electrical converter that converts the pedal stroke into voltage. This analog output voltage of the SWG2 is digitised in the control so that the pedal stroke is divided into 16 steps (positions).

Level	Position	Voltage [V]	Meaning
0	-2	0,00 - 0,50	Seam end, thread trimming
1	-1	0,50 - 0,94	Presserfoot up
2	0	0,94 - 1,76	Treadle position 0
3	+1	1,76 - 2,21	Presserfoot down
4	+1 D	2,21 - 2,43	Speed n1
5	+2 D	2,43 - 2,66	Speed n2
6	+3 D	2,66 - 2,90	Speed n3
7	+4 D	2,90 - 3,13	Speed n4
8	+5 D	3,13 - 3,37	Speed n5
9	+6 D	3,37 - 3,60	Speed n6
10	+7 D	3,60 - 3,84	Speed n7
11	+8 D	3,84 - 4,07	Speed n8
12	+9 D	4,07 - 4,31	Speed n9
13	+10 D	4,31 - 4,54	Speed n10
14	+11 D	4,54 - 4,78	Speed n11
15	+12 D	4,78 - 5,00	Speed n12

### contact connections of connection plug (X3) of the SWG2



## 7.4 External Operator Panel EcoTop AQE



The operator panel **EcoTop AQE** (Fig. 7.7) has the following components:

- **a display with two rows:** with a 16-characters LCD matrix each row
- **14 programming keys:** **A+ / A-**, **B+ / B-**, **C+ / C-**, **D+ / D-**, **P+ / P-**, **S+ / S-**, **L+ / L-**
- **two keys (T16, T17)** for selection of the operating mode
- **20 keys (T1...T15, T18...T22)** for machine functions

### Function of the programming keys in operating mode "manual sewing"

(key T16 is dark, key T17 is dark)

- **A+/A-** adjustment of stitchcount A/B start backtack
- **B+/B-** adjustment of stitchcount A/B start backtack
- **C+/C-** adjustment of stitchcount C/D end backtack
- **D+/D-** adjustment of stitchcount C/D end backtack

### Function of the programming keys in operating mode "programmed sewing"

(key T16 is bright, key T17 is dark)

- **A+/A-** adjustment of speed nx in program x
- **A+/A-** adjustment of stitchcount A/B start backtack
- **B+/B-** adjustment of stitchcount A/B start backtack
- **C+/C-** adjustment of stitchcount C/D end backtack
- **D+/D-** adjustment of stitchcount C/D end backtack
- **D+/D-** preselection of the program following program x
- **P+/P-** adjustment of program x (program number 1 ... 50)
- **S+/S-** adjustment of seam section (1...9) in program 1 ... 50
- **L+/L-** adjustment of the cycle counter for stacker activation
- **L+/L-** adjustment of stitchcount 0 ... 999 from a seam section

### Function of the programming keys in operating mode "parameter programming"

(key T16 is dark, key T17 is bright)

- **P+/P-** switch over of the hundreds of the parameter numbers
- **S+/S-** switch over of the parameter number in the switched on hundred section
- **L+/L-** programming of the parameter value of the switched on parameter number

## Function of the keys T16 and T17 for selection of the operating mode

- **T16** dark, **T17** dark: manual sewing
- **T16** bright, **T17** dark: programmed sewing
- **T16** dark, **T17** bright: parameter programming
- **T16** bright, **T17** flashes: teach in (s. chapter 9.1.1)

## Function of the programming keys (T1...T12, T13...T15) for machine functions

- **T1** linking for following seam sections (with / without)
- **T2** for speed control at programmed sewing:  
variable (treadle-controlled), if **T2** dark  
constant (automatic), if **T2** bright
- **T3** feed reverse for a seam section
- **T4** seam section manual or stitchcounted
- **T13** start backtack (on / off)
- **T14** end backtack (on / off)
- **T15** backtack inversion
- **T18** needle position at sewing stop (up / down)
- **T19** presser foot position at sewing stop (up / down)
- **T20** presser foot position after seam end (up / down)
- **T21** thread trimming (on / off)
- **T22** sewing with light barrier (on / off)

The keys **T1...T11** and **T15...T21** are provided with one signal lamp each (LED).

The key **T12** is without a signal lamp (LED).

The keys **T13**, **T14** and **T22** are provided with two signal lamps each (LED).

Each LED provides optical feedback on the control position of the function assigned to each key.

If the function is **ON**, the LED is **bright**;

if the function is **OFF**, the LED is **dark**.

## 7.5 Range of Application

Drive type J50EDx can only be used for one machine class.

Enabling of the machine-specific program is made by parameter <799> (for parameter programming please see Chapter 9.1.2.2).

Meanings:

<799> = 1      **Machine class 1: Lockstitch machines**



## 8. Application

This EcoDrive drive J50EDx can be only used with an external operator's control panel EcoTop.

### Switching on

The on/off switch (mains switch) S1 is located under the front of the sewing machine table. When activated, the control lamp of the switch S1 is lit.

### Maximum speed


The maximum speed can be adjusted with parameter <607> either with control panel EcoTop or with the mini control panel at the front of the control unit.

## 8.1 Sewing with External Operator's Control Panel EcoTop

### 8.1.1 Sewing without Sewing Program (manual Sewing)

Condition: key T16 (P/M) is dark  
key T17 (T/E) is dark


Display showing  
- before start or after start, if <605> = 0



Setting of rated stitches for stitch condensation is possible only with the machine at standstill  
 for front stitch condensation with key A+ or key B+ or  
 key A- or key B-  
 for end stitch condensation with key C+ or key D+ or  
 key C- or key D-

Display showing


- after start, when <605> = 1



## 8.1.2 Sewing with Sewing Program

Condition: key T16 (P/M) is bright  
 key T17 (T/E) is dark


Display showing before start



When this is displayed, the following can be modified:

- program: by actuating key P+ or P-
- seam section: by actuating key S+ or S-
- the number of seams in the selected program: by actuating key L+ or L-
- the subsequent sewing program via key D+ or D-
- rated speed for the program: by actuating key A+ or A-  
 for each program separately selectable  
 Display before start if a seam section has been activated  
 Display before start if a seam section has been activated


Display before start if a seam section has been activated




When this is displayed, the following can be modified:

- the rated stitches for stitch condensation for the program by actuating the keys located below the respective digits
- rated stitchcount of a seam section: by actuating key L+ or L-
- program: by actuating key P+ or P-
- seam section: by actuating key S+ or S-

Display showing after start, when <605> = 0



Display showing after start, when <605> = 1



### 8.1.3 Sewing programs

- a ) Number of sewing programs: 50
- b ) Number of seam sections per sewing program: 9
- c ) Number of stitches per seam section: max. 999
- d ) Adjustment of seam functions at the seam section:
- |  |             |
|--|-------------|
| start backtack / start stitch condensation   | via key T13 |
| end backtack / end stitch condensation   | via key T14 |
| needle position at sewing stop   | via key T18 |
| presser foot position at sewing stop   | via key T19 |
| presser foot position after seam end   | via key T20 |
| thread trimming  | via key T21 |
| Light barrier control  | via key T22 |
| Linking with the next seam section   | via key T1  |
| Sewing speed during programmed sewing  | via key T2  |
| <b>constant</b> (automatic), if <b>T2</b> is <b>bright</b><br>or <b>variable</b> (treadle controlled), if <b>T2</b> is <b>dark</b> |             |
| Feed reverse / stitch condensation   | via key T3  |
| Seam section manually or stitchcounted   | via key T4  |
- e ) Breaking of stitchcount  
Stitchcount of a seam section can be broken via treadle position "-2."-letter „M“ appears on the display. Manual sewing (without stitchcount) is now possible. Set treadle again at "-2" to complete seam section and advance the next one.
- f ) Seam section without stitchcount  
Seam sections can be also be sewn without stitchcount (manually):  
switch on T4 when T5 is off (LED dark). "m" on display signals manual seam section. For seam sections without stitchcount, display must show stitchcount  $\geq 1$ .  
Set treadle at "-2" to complete seam section and advance the next one.
- g ) Seam section with light barrier control  
The rated stitchcounts stored for this seam section are light barrier compensation stitches.
- h ) Sewing speed  
The sewing speed can be individually set for each program via display before starting the sewing operation. The maximum sewing speed to be programmed is defined by parameter <607>.
- i ) Interlinking of sewing programs  
It is possible to run several consecutive sewing programs. When programming, the subsequent program is displayed by digits 6 and 7 and can be entered via key D+ and D-.  
□1-□□ means that the current program will be performed exclusively; at its end return is made to its start.
- j) The programs can be used as **backtack or darning programs**  
Change-over is made via parameter <313>


#### 8.1.4 Backtack/Darning Programs ( <799> = 1 )

- The sewing programs are turned into backtack/darning programs when parameter <313> = 1.
- In each program, only seam sections 1 and 2 become active, section 1 being sewn forward and section 2 backward.
- The **darning program** is a special backtack program. In this case, reset the cycle counter to "0".
- Seam end is initiated in the darning program by treadle position "-2".
- 99 backtack/darning programs are available.
- The activated program is indicated on the display above keys P+/P-
- On the lefthand side of the display, the preset maximum speed possible in the program is shown before sewing start. This speed can be varied via the keys A+/A-
- The backtack/darning programs can be operated either at variable (treadle-controlled) or constant speed (not controlled by the treadle).
- Sewing at constant speed:  
With <313> = 0, switch on key T2 (luminous) during the seam sections, subsequently set <313> = 1; this means backtack/darning program activated.
- The end of seam is introduced in the backtack/darning program over pedal position „-2“.

## 8.5 Error Messages (Malfunction Diagnostics)

The control system of the drive cyclically tests its own functional condition and the functional condition of the complete drive system.

Malfunctions are signalled via the display of the external operator panel, for instance:



### Summary of the malfunctions:

Malfunction-No.	Reason	Remedy
1	Treadle not in zero position when mains power is turned ON.	Bring treadle in zero position, check the treadle, connect the Speed control unit.
9	Start lock is active. (during stop)	Eliminate cause.
10	Machine class (<799>) was changed.	Turn mains power switch OFF and ON again.
62	Short circuit on 24 V (32 V) DC.	Find short circuit and eliminate it Turn mains power switch OFF and ON again.
63	Overload on 24 V (32 V) DC, load current > 4 amps.	Turn mains power switch OFF and ON again search component (magnet), what was the reason why. Adjust new the magnet or change it.
64	voltage too low (90 V - 150 V) ( U < 150V ).	let check the voltage from a specialist.
65	Power electronics not operational after mains power ON, mains power < 130V.	Turn mains power switch OFF and ON again is the malfunction still happen, then change the control box.
66	Earth short (motor or motor supply line has earth short in one or more phases).	Change the control box or the motor.
67	Internal malfunction	Change the control box.
68	Power electronics shut-off when motor runs why: a) Overcurrent, short circuit in motor or supply line b) Overvoltage, mains voltage too high (>300 V), motor overloaded while decelerating c) Undervoltage	Eliminate cause.

<b>Malfunction-No.</b>	<b>Reason</b>	<b>Remedy</b>
<b>70</b>	Machine blocked, no increment from synchronizer at max. motor torque.	Eliminate cause.
<b>71</b>	Commutation transmitter plug not inserted	Insert commutation transmitter plug
<b>73</b>	Motor overloaded.	Eliminate cause.
<b>74</b>	No signal from the external Synchronizer	check the external Synchronizer check the Y-Adapter
<b>92</b>	Start lock while motor running. (during motor runs)	Eliminate the causing input signal and turn mains power switch OFF and ON again.
<b>173</b>	Governor disturbance: Startangle within control time not reached.	Turn hand wheel into needle position 2 (link take-up up), turn mains power switch OFF and ON again, start new. Change starting current with parameter <880> occurrence the repeated appearance.

## 8.3 Bobbin thread monitoring

### 8.3.1 Direct bobbin thread monitoring with bobbin thread watchdog

Parameter: <660> = 1  
<760> = x = stitch count for remnant thread after operation of the bobbin thread watchdog with **direct** bobbin thread monitoring

When the filling level of the bobbin has dropped below the switching point of the bobbin thread watchdog the output signal of the bobbin thread watchdog is active. Due to this there is a signal to input E13. This causes output A10 to be pulsed on (the signal LED "Bobbin thread error" on the machine flashes) and remnant stitch counting (<760>) is started.

When the remnant thread stitch counter reaches the value "0" the machine is stopped and the signal LED "Bobbin thread error" will be permanently on. The bobbin must now be changed. With pedal "-2" the bobbin thread watchdog is reset (restarted).

After a bobbin change the bobbin thread watchdog can be restarted at any time. To do this when the machine is not running the machine button S1 (transport change-over) has to be pressed and, at the same time, the pedal moved to position "-2".

### 8.3.2 Indirect bobbin thread monitoring with stitch count

Parameter: <660> = 2  
<605> = 0  
<760> = x = multiplier for the fixed value (200) for determining the starting value of the stitch counter with **indirect** bobbin thread monitoring using stitch counting.

In the display of the control panel EcoTop a four-digit number is brought into view on the left. This number is the count in the stitch counter for one bobbin pass. The start value of this number is a multiple of the fixed value 200. The multiplier for the fixed value is the value of the parameter <760>. While the machine is running the value in the counter is reduced (decreased) stitch for stitch.

On reaching the counter value "zero" the machine is stopped and output A10 is pulsed on (the signal LED "Bobbin thread error" on the machine flashes).

After pedal "zero" further stitching is possible with counter value "zero"; the LED is permanently on. With pedal "-2" the seam is finished, the stitch counter will be reset to the start value and the LED is switched off. A new bobbin must now be inserted.

After a bobbin change the bobbin thread watchdog can be restarted at any time. To do this when the machine is not running the machine button S1 (transport change-over) has to be pressed and, at the same time, the pedal moved to position "-2".



## 9. Programming by the user

Programming by the user is specific switching-on or adjustment of machine-functions and parameters.

User programming of the **EcoDrive** is possible either:

- the external operators panel (**EcoTop**)

User programming of the **EcoDrive** is possible via:

- **direct programming** and/or
- **programming parameters.**

The programming of parameters is possible via three levels of program:

- **Programming on level „a“** (operator level)
- **Programming on level „b“** (technician's level)
- **Programming on level „c“** (special level)

### 9.1 User programming with operator panel EcoTop AQE, DQE and FQE

#### Operator panel EcoTop AQE (Fig. 9.1) Lockstitch machines




Fig. 9.1

## 9.1.1 Direct Programming

Regardless of the programming levels, certain values can be programmed without calling up parameter numbers - i.e. directly.


### 9.1.1.1 Display from the lower display line

The following values can be modified by direct programming:


- Stitches for start backtack
- Stitches for end backtack
- Stitchcounts for seam sections
- Speeds for each seam
- Functions for seam sections
- Puller pressure
- Stitch length of the puller-roller

#### a) Modification of backtack / stitch condensation stitchcounts

Display shown when "manual sewing" is ON (T16 (P/M) and T17 (T/E) are dark.



Display shown when "programmed sewing" is ON (T16 (P/M) bright, T17 (T/E) dark.



The symbolic seam pictogram on the lefthand side of the operator panel shows the stitch condensation sections (missing with overlock machines)

A / B: backtack at seam start / stitch condensation at seam start / air sucking at seam start

C / D: backtack at seam end / stitch condensation at seam end / air sucking at seam start

Immediately below the display, there are keys


A+ / A- / B+ / B- for backtack at seam start / stitch condensation at seam start /  
air sucking at seam start

C+ / C- / D+ / D- for backtack at seam end / stitch condensation at seam end /  
air sucking at seam start

These keys permit to increase or decrease the number of stitches for backtack / stitch condensation.

## b) Programming of the Stitchcount for a Seam Section

Condition: Operation mode „**programmed sewing**“ is on, i.e. key T16 (P/M) is bright and key T17 (T/E) is dark, machine not sewing  
Display showing:



Activation of a **sewing program** is made via keys P+ or P-

Activation of a **seam section** is made via keys S+ or S-

Programming of the **stitchcount** for the seam section is made via key L+ (value increased) or L- (value decreased).

### c) Programming of Seam Sections by „Teach-in“ (Performing Work)

Condition: Key T16 (P/M) is bright  
Key T17 (T/E) **flashes!**

The machine must have performed at least one stitch before.

Activate the desired program in the display via keys P+ or P- and the seam section to be programmed via keys S+ or S-.

Cycle:

- a) Treadle forward  
Reaction: the stitchcount which has been registered up to now will be eliminated
- b) Treadle returns to zero position
- c) Treadle forward  
Reaction: machine sews, the sewed stitches will be added in, shown in the display and registered
- d) Treadle returns to zero position
- e) push Key T17, the values will be saved.

Correction of the value shown in the display is possible via key L+ or L-.

### d) Programming of Functions

Functions for the seam sections are controlled via the functional keys


- |     |  |
|-----|--|
| T13 | start backtack / start stitch condensation / vacuuming at seam start (with/without)                  |
| T14 | end backtack / end stitch condensation / vacuuming at seam end (with/without)                        |
| T18 | Needle position at sewing stop and at the end of a seam section (up/down)                            |
| T19 | Presser foot position at sewing stop (up/down)   |
| T20 | Presser foot position at the end of a seam section (up/down)   |
| T21 | Thread trimming at the end of a seam section (with/without)  |
| T22 | Sewing with light barrier (with/without)   |
| T1  | Linking of seam section (with/without),  |
| T2  | Speed control,<br>variable (treadle-controlled, T2 is dark) or<br>constant (automatic, T2 is bright) |
| T3  | Transport reverse or stitch condensation of a seam section   |
| T4  | Seam section manual or stitchcounted   |

### 9.1.1.2 Display of the upper display line


The following values can be shown and modified by direct programming:

- Control box type and Software number
- Values of the puller
- for example BDE data etc..

After switched on there appears **shortly** this display :



Then this display appears:



#### Proceeding

Switching the key allocation to the upper display line occurs by pressing the ESC key (LED is bright).

#### Attention

After switching the key allocation to the upper display line (LED of the key "ESC" is bright) "A, B, C, D" and "P" are disabled for normal functions.

#### Exceptions

In the parameter programming mode the keys "P, S, and L" have their original meaning (LED of the key T/E is bright) in the program mode, key "S" switches to seam sections (LED of the key P/M is bright)

#### Adjust the puller values:

With key „S+“ or „S-“ there is possible to change the value of the puller-pressure.

With key „L+“ bzw. „L-“ there is possible to change the value of the stitch length of the puller-roller.

After programming press key „ESC“, LED of the key "ESC" is dark, the programming is finished.

### 9.1.1.3 Programming of the puller pressure and stitch length of the puller roller

#### Description from the functions of the needed parameters:

P. 252 = Raise level of the puller (linear motor) with AR

P.253 = Angle for start of puller during intermittent operation.

P.254 = Raise level of the puller (linear motor) with ER and after seam end

P.261 = Correction factor for the puller roller feed

P.262 = Transportation length (angle) of the puller roller

P.264 = Current for puller drive after switch on

P.265 = Run time of the puller roller after switch on

P.302 = Positional holding current of the linear motor

P.445 = Stitches for puller delay

P.499 = Number of stitches for slowed down lowering of puller after operating switch S8 (knee switch)

#### Adjusting from the parameter:

Activation of programming level „b“  
(see chap. 9.1.2.2 Programming Level „b“)

Press key T/E  
LED from key T/E is bright,  
Modification of parameter number:  
for hundreds of parameter numbers use key P+ or P-  
for tens and units of parameter numbers use key S+ or S-

The value can be changed with key L+ / L- .


After input press key T/E,  
LED from key T/E is dark, programming is finished.

#### Adjusting from the puller:

Press key ESC on the operator panel EcoTop,  
LED from ESC-key is bright,

the upper display line is activ!

The value from **puller pressure during sewing** can be changed with key S+ / S- .



The value from **stitch length of the puller roller** can be changed with key L+ / L- .

After input press key ESC,  
LED from key ESC is dark, programming is finished.

## 9.1.2 Parameter Programming

### 9.1.2.1 Programming Level „a“ (Operator Level)

This level is used for programming control parameters which immediately affect the operation sequence.

These are the parameters for the following functions:

- Light barrier compensation stitches <111>
- Light barrier fade-out <112>
- Softstart stitches <116>

#### a) Activation of Programming Level „a“

Conditions

Mains power switch ON

Drive system not running

Operating mode: manual sewing must be ON (key T16 (P/M) dark)

The Display shows a "a"

<799> = 1 Lockstitch machines




Press key T17 (T/E)

Response:

Key T17 (T/E) becomes bright, the display shows in its righthand half the first parameter (parameter no. and parameter value) associated with programming level "a".

Sewing is not possible!



- Programming  
The parameter number is set by using keys P+ or P- (hundreds of parameter no.) and keys S+ or S- (tens and units of parameter no.). The parameter value is programmed by using key L+ or L-


## b) Deactivation of the Programming Level „a“

Press key T17 (T/E)

Response:

Key T17 (T/E) goes dark, the display returns to initial condition.  
Sewing is possible.

<799> = 1 Lockstitch machines



### 9.1.2.2 Programming Level „b“ (Technician Level)

This level is used for programming the control parameters which have to be modified or adapted very rarely or only for starting operation of the system.


#### a) Preparation for activation of the programming level „b“

Turn mains power switch OFF  
Press and hold keys T16 (P/M) and T17 (T/E) simultaneously  
Turn mains power switch ON  
Release keys

Response:

The display shows a „b“ between program and seam section.  
Sewing is possible.

<799> = 1 Lockstitch machines



#### b) Activation of programming level „b“

Press key T16 (P/M) (not becoming bright) and press key T17 (T/E) (becoming bright)

Response:

In the righthand half of the display are shown: a parameter number (at first 104, then the number selected last) and the associated value.

Sewing is not possible!



Modification of parameter number:

for hundreds of parameter numbers use key P+ or P-

for tens and units of parameter numbers use key S+ or S-

Modification of parameter value:

via key L+ or L-




### c) Deactivation of programming level „b“

Press key T17 (T/E) (not becoming bright)

Response:

Parameters shown disappear from the display, the display returns to initial condition  
Sewing is possible!

<799> = 1 Lockstitch machines



### 9.1.2.3 Programming Level „c“ (Special Level)


#### Attention!

At this level, control parameters are stored which have to be modified in exceptional cases only. Correction of these parameters should therefore be made only after consultation of the manufacturer.

#### Activation of programming level „c“

- a) Activate programming level „b“ (see 9.1.2.2)
- b) Call up parameter 798
- c) Set parameter value <798> to ON
- d) Turn mains power switch OFF, wait for >2 secs. to elapse
- e) Turn mains power switch back ON, programming level „c“ is activated!


<799> = 1 Lockstitch machines



- f) Press key T17 (T/E) (becoming bright)

Response:

In the righthand half of the display appears the first parameter of programming level c. The display shows a „c“ between program and seam section.



Calling up further parameter numbers and correcting the parameter values can be made in the same way as described for programming levels „a“ and „b“.

#### Deactivation of programming level "c"

- Press key T17 (T/E) (becoming dark)
- Turn mains power switch OFF.

### 9.1.3 Reset

#### a) Reset of parameter values


All parameter values having been modified from the ex-factory condition (standard value) are reset to their standard values by this procedure.

**Exceptions:** parameters 700, 799 and 800 and further parameters signed with „\*“  
For these parameters, the values programmed by the user are retained even after -Reset- has been performed.


-Reset- procedure:

- turn mains power switch OFF
- press treadle fully forward and hold in that position
- press and hold keys P+ and L+ simultaneously
- turn mains power switch ON
- release the three keys and the treadle


Response: Display showing



Now -Reset- can be performed.  
Located below the display Y (yes) there is key P+. Press this key P+ to start the reset.  
Press key L+ to abort Reset!  
After -Reset- appears for a short time this display:



After that the display shows the power-on display for approx. 2 secs, for example:



and then shows the display corresponding to the operating mode selected


<799> = 1 Lockstitch machines




If it is not desired to start the -Reset-, press key L+ located below the display saying N (no).

## b) Reset of the sewing programs

The reset procedure of the sewing programs is analog to that described under a), until the following appears in the display:




In order to reset the data of the sewing programs to their original values, it is now required before pressing key **P+** to press at first key **T13** and hold until activation is acknowledged in the display. After -Reset- appears for a short time this display:




## c) Reset of parameter values and sewing programs

The reset procedure including the data of the sewing programs is analog to that described under a), until the following appears in the display:



In order to reset the parameters and the data of the sewing programs to their original values, it is now required before pressing key **P+** to press at first key **T15** and hold until activation is acknowledged in the display.

After -Reset- appears for a short time this display:



## 10. Start of operation

If the **EcoDrive** has been stored at a temperature of  $<+5^{\circ}\text{C}$ , then a working temperature of between  $+5^{\circ}\text{C}$  and  $+45^{\circ}\text{C}$  must first be obtained.  
The equipment must be dry.

Before work with the machine can be started, make sure to perform the following:

- a) Control the direction of rotation and the reference position of the needle bar
- b) Control the needle positions
- c) Control the maximum speed

### 10.1 Control of the direction of rotation and of the reference position from the needle bar (needle position NP0)

- a) Activate programming level „b“ (technician level) (see section 9.1.2.2 „programming level „b““)
- b) Set parameter 700
- c) Actuate treadle briefly forward:  
Reaction: The machine performs a full revolution and then positions in a random position.
- d) Is the direction of rotation correct?  
When yes, then proceed to adjust the reference position, proceed with e) below  
If no, then activate parameter 800 and change the value  $<800>$  ( $1 \rightarrow 0$  or  $0 \rightarrow 1$ )  
than proceed as b)
- e) Turn the handwheel of the machine in the direction of rotation until the **point of the needle coming from up** to down touches the level of the throat plate (= reference position).  
When doing this it is important that parameter  $<701> = 1$ .
- f) Actuate the treadle briefly forward:  
Reaction: The machine performs one revolution and positions in the same position that had been previously obtained by hand.
- g) As soon as new parameter numbers are activated, or the programming level „b“ is negated, then the parameter value  $<700>$  is memorized and the reference position adjustment is completed.

By correct mounting of the tooth belt (see chapter 6.2 in part 1), the zero position (reference position) of the machine shaft can be made to coincide with the zero position of the incremental encoder (rotor position encoder) of the motor.

### 10.2 Learning procedure of the speed ratio

Is needed, if the engine drives the machine about a v-belt, or in the case of a reduction ratio from engine to machine (unequally 1:1).

Condition for hardware: Y-adapter, synchronizer PD3 or another signal generator, which supplies exactly one impulse per revolution. After first power-on or master reset the control recognizes the attached y-adapter.

In the display the announcement appears PULLEY in the upper line. With pedal forward the learning phase is introduced. The drive runs in low speed, until the learning phase is concluded.  
This procedure cannot be interrupted!

In the display the announcement becomes PULLEY deleted. Learn in the angle adjustment angle:  
When adjusting the logical zero-mark (parameter  $< 700 >$ ) the learning procedure is repeated. It does not take place a separate announcement in the display.

Error message: After kind of sewing and one waiting period if no signal is recognized by the external giver, ERROR 74 is indicated, the drive holds without position. Remedy: external giver examine, if necessary change.

## 10.3 Control of the needle positions NP1 / NP2

NP1 - needle down position (<702>)

NP2 - thread take up lever in the up position (<703>)

- a) Activate programming level „b“ (technician level) (see section 9.1.2.2 „programming level „b““)
- b) Activate parameter 702
- c) Actuate the treadle briefly forward  
Reaction: The machine performs a revolution and then positions at the programmed <702>.
- d) Is the needle position correct?  
When yes, then proceed as with g) below.  
When no, then the position must be changed by turning the hand wheel (when <701> = 1) or via key L+ or L- (when <701> = 0) at the **EcoTop**
- e) Actuate the treadle briefly forward  
Reaction: The machine performs a revolution and positions in the same position.
- f) The position can again be corrected.  
When no further correction is needed, then proceed as with g) below.
- g) As soon as another parameter number is called up, e.g. example 703, the previously programmed value of <702> is memorized.
- h) With parameter 703 and 710 correction is obtained as described above for parameter 702.
- i) Deactivate programming level „b“ (see section 9.1.2.2 „programming level „b““).

## 10.4 Control of the maximum speed

- a) Activate programming level „b“ (see section 9.1.2.2 "programming level „b““)
- b) Set to parameter 607
- c) Check the parameter value <607> and make correction if necessary via keys L+ or L- at the **EcoTop**
- d) Deactivate programming level „b“ (see section 9.1.2.2 "programming level „b““).

## 10.5 Hardware Test

Hardware Test is a check routine permitting to use the operator panel **EcoTop** for testing various components of the drive system (control system) and of the machine installation.

### Activation of the „HARDWARE TEST“ routine

- Activate programming level „c“ and call up parameter 798
- Set <798> to ON
- Turn off mains switch **S1**
- Wait for approx. 2 secs. to elapse, and turn on main switch S1 again
- Programming level „c“, call up parameter 797
- Set <797> to ON

Response: The display shows for approx. 2 secs:

#### Indication EcoTop:



After that, the display shows the first test block: Inputs.  
All EcoTop keys equipped with LEDs become bright

To call up the test blocks (advancing from test block to test block):

use keys **A+** and **A-** on the **EcoTop**

### Survey of test blocks:


Test-Block	Check	Indication EcoTop
1	Inputs	
2	Outputs	
3	Speed control-unit	
4	Synchronizer	

**Survey of test blocks:**

**Test-Block Check**

**Indication EcoTop**

5 Functions  
for data transfer




This Display of the upper display line **1:ED → ET** means:  
Use **Key 1** to transfer data from EcoDrive to the operator panel EcoTop.

This Display of the upper display line **2:ET → ED** means:  
Use **Key 2** to transfer data from operator panel EcoTop to the EcoDrive.

This Display of the lower display line **4:ED → QP** means:  
Use **Key 4** to transfer data from EcoDrive to the Q-Prog.

This Display of the lower display line **5:QP → ED** means:  
Use **Key 5** to transfer data from the Q-Prog to the EcoDrive.

6 Puller




**Hint:** further indications on the display are for optional functions!



To call up various functional elements within a test block such as advancing from an Input to the next, use keys B+ and B- on the control panel **EcoTop**.

To activate functional elements selected, use key **D+** othe **EcoTop**.

**Test block 1: Inputs**  
Display:



The function assigned to the input displayed can be seen from chapter 12 „Connections Diagram for Connectors“.

The designations E (for input) are located on the lefthand side of the connectors shown.

The keys or selectors assigned to the inputs are designated S in the connections diagram and have the same numbers as the associated inputs, i.e.

key S1 is connected to input E1

key S2 is connected to input E2

key Sx is connected to input Ex.


The operating state of the input is signalled in the 7th digit of the display.

Key/switch open → display: 0

Key/switch closed → display: 1

In the righthand part of the display, the connecting plug and the pin number to which the displayed input is connected are shown for the purpose of reference.

**Test block 2: Outputs**  
Display:



The function assigned to the ouput displayed can be seen from chapter 12 „Connections Diagram for Connectors“.


The designations A (for output) are located on the lefthand side of the connectors shown.  
 The solenoids/solenoid valves assigned to the outputs are designated Y in the connections diagram and have the same numbers as the associated outputs, i.e.  
 solenoid Y2 is connected to output A2  
 solenoid Y3 is connected to output A3  
 solenoid Yx is connected to output Ax

The operating state of the output displayed is signalled in the 7th digit of the display.  
 Output not activated → display: 0  
 Output activated → display: 1

To activate an output, use key D+ on the control panel **EcoTop**. Deactivation is made automatically after approx. 2.5 secs have elapsed or can be caused by using key D-.

In the righthand part of the display, the connecting plug and the pin number to which the displayed output is connected are shown for the purpose of reference.

**Test block 3:** Speed control unit (SWG)  
 Display:




The treadle can be actuated to operate consecutively all 16 steps of the speed control unit.

The following is displayed in digits 5, 6, 7 and 8

-2 / -1 / 0 / +1 / 10 / 20 / ... / 120, when the speed control unit is in proper condition.

**Test block 4:** Synchronizer (IWG)  
 Display:



This test block permits to check the synchronizer (increment encoder). For this purpose, the shaft of the motor is rotated manually.

The increments (pulses) of the synchronizer are counted and shown in display digits 14, 15 and 16. This display runs from 0 through 255 when the synchronizer is in proper condition.

**To deactivate the test routine**, turn the mains power switch OFF, or press the ESC-Key.

## 10.6 Transfer of parameter and sewing program data with EcoTop operator panel (quick configuration for multiple machines)

The control J50Edx offers the possibility to quickly and easily transfer operator specific settings such as parameters and sewing programs via EcoTop from one machine to another with the same control.

### Directions:

In order to transfer data from the Eco Drive control to the EcoTop operator panel, it is necessary to activate the **Hardware-Test!**

Hardware Test is a check routine permitting to use the operator panel **EcoTop** or the **mini programming panel (MPF)** for testing various components of the drive system (control system) and of the machine installation.

### Activation of the „HARDWARE TEST“ = „HW-Test“ routine

- Activate programming level „c“ and call up parameter <798>
- Set <798> to ON
- Turn off mains switch
- Wait for approx. 2 secs. to elapse, and turn on main switch again
- Programming level „c“, call up parameter <797>
- Set <797> to ON


Response: The display shows for approx. 2 secs: „HARDWARE-TEST“

#### Indication EcoTop:



After that, the display shows the **first test block**: Inputs.  
All EcoTop keys equipped with LEDs become bright


#### Indication EcoTop:



To call up the test blocks (advancing from test block to test block), use keys **A+** and **A-** on the **EcoTop**

Select **test block 5 (for data transfer)** with key **A+** or **A-**.

#### Indication EcoTop:




## 10.6.1 Parameter transfer from EcoDrive to EcoTop

**Attention:** only **parameter** data will be transferred.


Through pressing **Key 1** on the **EcoTop** operator panel, the transfer of **parameter data** from **EcoDrive** control to operator panel **EcoTop** is activated.

A short **message** appears:



DRIVE->TOP START  
4:ED>QP 5:QP>ED


After successful data transfer, the following **message** appears:



DRIVE -> TOP OK  
4:ED>QP 5:QP>ED

**Attention:** the parameter data has been transferred and is stored in the **EcoTop** operator panel and is ready to be applied to multiple machines with the same type of control box.

Upon completion, the following **message** appears:




1:ED>ET 2:ET>ED  
4:ED>QP 5:QP>ED

## 10.6.2 Parameter transfer from EcoTop to EcoDrive

**Attention:** only **parameter** data will be transferred.

Through pressing **Key 2** on the **EcoTop** operator panel, the transfer of **parameter data** from **EcoTop** to **EcoDrive** control is activated.

A short **message** appears:



TOP->DRIVE START  
4:ED>QP 5:QP>ED


After successful data transfer, the following **message** appears:



TOP -> DRIVE OK  
4:ED>QP 5:QP>ED

**Attention:** the parameters have been transferred and stored to the EcoDrive control!

Upon completion, the following **message** appears:



### 10.6.3 Parameter and sewing program data transfer from EcoDrive to Q-Prog programming device


**Attention:** Parameters and sewing programs can be transferred in this modus. The programming device **Q-Prog (part number 66.022)** and a zero-modem cable (available at a local electronics/computer dealer) is required to perform these functions!

Through pressing **Key 4** on the **EcoTop** operator panel, the transfer of **parameter data and sewing program data** from **EcoDrive** control to **Q-Prog** is activated.


A short **message** appears:




In the event that no **Q-Prog** or **cable** is connected, the following **message** appears:



Upon successful data transfer, the following **message** appears:



**Attention:** The above message appears until a new modus through pressing key **A+** or **A-** is selected, for example:



**Exit the hardware test and programming modus by pressing the ESC key.**

## 10.6.4 Parameter and sewing program data transfer from Q-Prog programming device to EcoDrive

**Attention:** **Parameters** and sewing **programs** can be transferred in this modus.  
The programming device **Q-Prog (part number 66.022)** and a zero-modem cable (available at a local electronics/computer dealer) is required to perform these functions!

Through pressing **Key 5** on the **EcoTop** operator panel, the transfer of **parameter data and sewing program data** from **Q-Prog** control to **EcoDrive** is activated.

A short **message** appears:

A rectangular LCD display with a green background and black text. The text reads "QPRG»DRIVE START" in a monospaced font. The display is divided into two rows by a horizontal line. The first row contains "QPRG»DRIVE" and the second row contains "START".

In the event that no **Q-Prog** or **cable** is connected, the following **message** appears:

A rectangular LCD display with a green background and black text. The text reads "TIMEOUT" in a monospaced font. The display is divided into two rows by a horizontal line. The first row contains "TIMEOUT" and the second row is empty.

Upon successful data transfer, the following **message** appears:

A rectangular LCD display with a green background and black text. The text reads "READY" in a monospaced font. The display is divided into two rows by a horizontal line. The first row contains "READY" and the second row is empty.

**Attention:** The above message appears until a new modus through pressing key **A+** or **A-** is selected, for example:

A rectangular LCD display with a green background and black text. The text is arranged in two rows. The first row shows "1:ED»ET 2:ET»ED" and the second row shows "4:ED»QP 5:QP»ED". The display is divided into two rows by a horizontal line.

Exit the hardware test and programming modus by pressing the **ESC** key.