


PARTS BOOK

FOR

BROTHER EF4-B958




Please clarify Ref. No. and
Parts No. as well as parts name
When you place an order.

BROTHER INDUSTRIES, LTD.

NAGOYA, JAPAN.

Z




Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.
Z-1	Accessory Box	1 pce.	110436-0-01		Z-18	Oil	1	114483-0-01	
Z-2	Needle Bag	1	108962-0-01		● Z-19	Trimming Knife	1	118856-0-01	
Z-3	Needle DC x 1	10 pcs.	112297		Z-20	Head Cover	1	144225-0-01	
Z-4	Wrench 10 x 12	1 pce.	107780-0-01		● Z-21	Chain	1	106812-0-01	
Z-5	Wrench 7-8	1	142205-0-01		Z-22	Foot Pedal	1	117437-0-01	
Z-6	Allen Wrench (3mm)	1	142721-0-01		Z-23	Foot Pedal Stopper	2 pcs.	116016-0-01	
● Z-7	Screw for Cushion Base	4 pcs.	031451-6-03		Z-24	Screw	2	001401-4-06	
Z-8	Cotton Stand (No. 3)	1 pce.	142973-0-01		Z-25	Nut	2	021400-1-06	
● Z-9	Screwdriver 2.6 x 70	1	105344-0-01		● Z-26	Tweezer	1 pce.	117466-0-00	
● Z-10	Screwdriver 5.5 x 75	1	102629-0-04						
Z-11	Screwdriver 5.5 x 200	1	101572-0-01						
● Z-12	Screw	1	105123-0-01						
● Z-13	Edge Hemming Ruler (A)	1	143552-0-01						
● Z-14	Edge Hemming Ruler (B)	1	112465-0-01	112464-0-01					
● Z-15	Adjusting Screw	1	112466-0-01						
● Z-16	Bolt	1	112398-0-01						
Z-17	Oil	1	145277-0-01						

Remark:

- ※ The parts with mark (·) are in accessory box.
 - ※ The following parts are enclosed in the accessory for our packing convenience.
- Ref. No. A-84, A-85, A-86


Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark	Parts No.	Ref. No.	Remark
11887-0-01	D-16										
11899-0-01	C-4										
14024-0-01	A-111										
140506-0-01	E-5										
140507-0-01	F-29										
140508-0-01	E-8										
140509-0-01	E-4										
	E-34										
140529-0-01	D-47										
140792-0-01	C-7										
140839-0-01	B-84										
142205-0-01	Z-5										
142590-0-01	B-31										
	C-38										
	D-5										
	E-9										
142664-0-00	A-77										
142721-0-01	Z-6										
142952-0-01	C-83										
142973-0-01	Z-8										
143271-0-01	A-82										
143272-0-01	A-82										
143304-0-01	A-82										
143373-0-01	B-67										
143552-0-01	Z-13										
144103-0-01	A-23										
144105-0-00	A-25										
	A-50										
	A-70										
144106-0-01	A-26										
144225-0-01	Z-20										
144609-0-01	C-57										
145277-0-01	Z-17										
145446-0-01	A-22										
	A-52										
	A-68										
146023-0-01	B-89										
146024-0-00	B-88										
400163-0-01	A-1										
	A-114										

A




Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.
A-1	Set Screw for A-2	2 pcs.	100163-0-01		A-59	Stopper Stud for A-75	1 pce.	112251-0-01	
A-2	Cloth Guide	1 pce.	112244-0-01		A-60	Set Screw for A-59	1 -	100218-0-02	
A-3	Cover for B-65	1 -	112243-0-01		A-61	Guide Pipe for Under Looper Thread	1 -	112444-0-01	
A-4	Set Screw for A-3	2 pcs.	100644-0-01		A-62	Hinge Shaft for A-75	1 -	112238-0-01	
A-5	Stopper Shaft for A-7	1 pce.	112241-0-01		A-63	Under Looper Thread Tension Guide	1 -	112434-0-01	
A-6	Nut for A-5	1 -	102571-0-03		A-64	Cloth Plate Cover Hinge	1 -	112237-0-01	
A-7	Needle Bar Cover	1 -	112238-0-01		A-65	Set Screw for A-61	2 pcs.	100541-0-01	
A-8	Hinge Pin for A-7	2 pcs.	112239-0-01		A-66	Looper Tension Control Stud	1 pce.	110820-0-01	
A-9	Stopper Spring for A-7	1 pce.	112240-0-01		A-67	Felt for A-68	1 -	110832-0-01	
A-10	Set Screw for A-9	1 -	105123-0-02		A-68	Tension Disc	2 pcs.	145446-0-01	
A-11	Arm	1 -	112222-0-01		A-69	Under Looper Tension Spring	1 pce.	115958-0-01	
A-12	Set Screw for A-11	2 pcs.	018082-5-22	112452-0-01	A-70	Tension Spring Washer	1 -	144105-0-00	
A-13	Spring Pin	2 -	112224-0-01		A-71	Thread Tension Adjusting Nut	1 -	105230-0-01	
A-56	Machine-Body	1 pce.	112221-0-01		A-72	Cloth Plate	1 -	112246-0-01	
A-14	Top Cover Window Plate	1 -	112244-0-01		A-73	Cushion for A-75	1 -	115808-0-01	
A-15	Top Cover	1 -	112233-0-01		A-74	Under Looper Thread Guide	1 -	112252-0-01	
A-27	Name Plate "BROTHER"	1 -	112237-0-01		A-75	Cloth Plate Cover	1 -	112245-0-01	
A-30	Pulley Cover	1 pce.	112232-0-01	112453-0-01	A-76	Set Screw for A-72	3 pcs.	100698-0-02	
A-35	Packing Right for A-14	1 -	112235-0-01		A-77	Over Looper Crank Cover Assembly	1 pce.	142964-0-00	
A-36	Packing Left for A-14	1 -	112236-0-01		A-78	Washer for A-77	2 pcs.	112315-0-01	
A-16	Set Screw for A-15	1 -	114724-0-01		A-79	Set Screw for A-77	2 -	105123-0-02	
A-17	Thread Guide	1 -	115860-0-01		A-80	Set Screw for A-81	1 pce.	111283-0-01	
A-18	Nut for A-17	1 -	112262-0-01		A-81	Cloth Plate Stopper	1 -	111282-0-01	
A-19	Needle Thread Guide	1 -	110813-0-01		A-82	Medallion for EF4-B958-01	1 -	143304-0-01	
A-20	Needle Thread Tension Control Stud	1 -	110820-0-01		-	Medallion for EF4-B958-01	1 -	143271-0-01	
A-21	Felt for A-22	1 -	110832-0-01		-	Medallion for EF4-B958-11	1 -	143272-0-01	
A-22	Tension Disc	2 pcs.	145446-0-01		A-83	Pin for A-82	2 pce.	116231-0-01	
A-23	Tension Disc Washer	1 pce.	144103-0-01		A-84	Cushion Base Assembly	2 -	115951-0-01	
A-24	Needle Thread Tension Spring	1 -	115956-0-01		A-85	Cushion	4 -	115854-0-01	
A-25	Tension Spring Washer	1 -	144105-0-00		A-86	Wood Screw 4.5x16 for A-84	4 -	031451-6-03	
A-26	Thread Tension Adjusting Screw	1 -	144106-0-01		A-87	Washer for A-86	1 -	112250-0-01	
A-28	Set Screw for A-15	2 pcs.	105328-0-03		A-88	Set Screw for A-89	2 -	107631-0-01	
A-31	Over Looper Thread Guide	1 pce.	114724-0-01		A-89	Plate Spring for A-75	1 pce.	112249-0-01	
A-32	Inside Cover Assembly	1 -	118469-0-01		A-90	Nut for A-91	4 pcs.	112262-0-01	
A-33	Set Screw for A-32	5 pcs.	100257-0-06		A-91	Set Screw for A-97	4 -	115955-0-01	
A-34	Packing for A-32	1 pce.	112255-0-01		A-94	Packing for A-95	1 -	112348-0-01	
A-37	Upper Knife Cover Assembly	1 -	116021-0-01		A-95	Cap Screw	1 -	112467-0-01	
A-39	Set Screw for A-37	1 -	116024-0-01		A-96	Oil Gauge Indicator	1 -	112260-0-01	
A-40	Stopper Shaft for A-42	1 -	112231-0-01		A-97	Oil Pen	1 -	112258-0-01	
A-41	Set Screw for A-40	1 -	104651-0-01		A-98	Packing for Oil Pan	1 -	112486-0-01	
A-42	Front Cover Assembly	1 -	112225-0-01		A-99	Set Screw for A-100	2 -	101185-0-03	
A-43	Front Cover Knob	1 -	112229-0-01		A-100	Looper Cover	1 pce.	112253-0-01	
A-44	Stopper Spring for A-42	1 -	112230-0-01		A-101	Looper Inside Cover	1 -	115959-0-01	
A-45	Nut for A-44	1 -	109129-0-01		A-102	Set Screw for A-101	1 -	100191-0-03	
A-46	Set Screw for A-42	2 pcs.	100137-0-03		A-103	Driving Shaft Cover	1 -	117435-0-01	
A-47	Thread Guide for D-30	1 pce.	112448-0-01		A-104	Set Screw for A-103	1 -	100541-0-01	
A-48	Set Screw for A-47	1 -	105123-0-02		A-105	Wick for A-103	2 pcs.	117432-0-00	
A-49	Thread Tension Adjusting Screw	1 -	112447-0-01		A-106	Upper Knife Driving Lever Cover	1 pce.	117434-0-01	
A-50	Tension Spring Washer	1 -	144105-0-00		A-107	Set Screw for A-106 & A-104	2 pcs.	105123-0-02	
A-51	Over Looper Tension Spring	1 -	115957-0-01		A-108	Nut for A-107	2 -	106129-0-01	
A-52	Tension Disc	2 pcs.	145446-0-01		A-109	Wick for A-106	2 -	117431-0-00	
A-53	Felt for A-52	1 pce.	110832-0-01		A-110	Needle Bar Rod Cover	1 pce.	117433-0-01	
A-54	Looper Tension Control Stud	1 -	110820-0-01		A-111	Under Looper Thread Guide A	1 -	140284-0-01	
A-55	Over Looper Thread Guide	1 -	112446-0-01		A-112	Set Screw for A-111	1 -	105123-0-02	
					A-113	Trimming Knife	1 -	118656-0-01	
					A-114	Set Screw for A-113	2 pcs.	100163-0-01	

B




Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.
B-1	Needle Thread Take-up Guide	1 pce.	112302-0-01		B-48	Set Screw for B-47	1 pce.	013780-8-14	
B-2	Set Screw for B-1	1 -	100257-0-06		B-49	Wick for B-47	1 -	112474-0-01	
B-3	Needle Bar Bushing, Lower	1 -	112372-0-00		B-50	Set Screw for B-54	1 -	112398-0-01	
B-6	Needle Bar	1 -	112295-0-01	143373-0-01	B-51	Washer for B-54	1 -	112399-0-01	
B-7	Needle Clamp Nut	1 -	112296-0-01		B-52	Presser Foot Stitch Tongue for 3mm-5mm	1 -	112472-0-01	
B-8	Needle (DC-1)	1 -	112297-0-11		B-53	Set Screw for B-52	1 -	112397-0-01	
B-9	Set Screw for B-10	1 -	100064-0-03		B-54	Sub Presser Foot	1 -	112380-0-01	112389-0-01
B-10	Needle Bar Clamp	1 -	112294-0-01		B-55	Presser Foot Spring	1 -	112393-0-01	for B958-01
B-11	Set Screw for B-10	1 -	100130-0-02		B-56	Stop Pin for B-55	1 -	112394-0-01	8-11
B-12	Needle Thread Guide Plate	1 -	112298-0-01		B-57	Set Screw for B-56	1 -	104651-0-01	
B-13	Set Screw for B-12	1 -	009660-4-12		B-58	Main Presser Foot	1 -	112391-0-01	
B-14	Needle Thread Guide	1 -	112300-0-01		B-59	Pin for B-58	1 -	112392-0-01	
B-15	Spring for B-12	1 -	112299-0-01		B-61	Presser Foot Arm -	1 -	112388-0-01	
B-16	Stud Screw for B-12	1 -	112301-0-01		B-62	Set Screw for B-63	1 -	100388-0-04	
B-17	Wick for B-18, B-19	2 pcs.	112293-0-01		B-63	Stud Shaft for B-61	1 -	112374-0-01	
B-18	Needle Bar Link Shaft	1 pce.	112292-0-01		B-64	Stud Screw for B-65	1 -	112404-0-01	
B-19	Needle Bar Link Shaft	1 -	112292-0-01		B-65	Presser Foot Lifter Lever	1 -	112403-0-01	
B-20	Set Screw for B-22	2 pcs.	117428-0-01		B-66	Spring for B-65	1 -	112407-0-01	
B-21	Needle Bar Link	1 pce.	112291-0-01		B-67	Nut for B-68	1 -	112406-0-01	
B-22	Needle Bar Driving Lever	1 -	112290-0-01		B-68	Adjusting Screw	1 -	112405-0-01	
B-23	Set Screw for B-19	1 -	100130-0-02		B-69	Presser Spring for B-65	1 -	112400-0-01	
B-24	Cap Screw for B-22	1 -	00185-0-04		B-70	Presser Adjusting Screw	1 -	112401-0-01	
B-25	Set Screw for B-26	1 -	112287-0-01		B-71	Movable Presser Foot Upper	1 -	117740-0-01	
B-26	Needle Bar Driving Lever, Shaft	1 -	112288-0-01		B-72	Movable Presser Foot Lower	1 -	117741-0-01	
B-27	Needle Bar Driving Shaft Bushing (front)	1 -	112273-0-00		B-73	Pin for B-72	1 -	117742-0-00	
B-28	Needle Bar Driving Shaft Bushing (rear)	1 -	112274-0-00		B-74	Main Movable Presser Foot	1 -	112391-0-01	
B-29	Round Joint for B-30	1 -	112286-0-01		B-75	Pin for B-74	1 -	112392-0-01	
B-30	Needle Bar Connecting Rod	1 -	112284-0-00		B-76	Movable Presser Foot Spring	1 -	112393-0-01	117743-0-01
B-31	Stud Screw for B-30	4 pcs.	142590-0-01	112455-0-01	B-77	Stop-Pin for B-76	1 -	112394-0-01	for B958-06
B-32	Round Joint Guide	1 pce.	112285-0-01		B-78	Set Screw for B-77	1 -	104651-0-01	
B-33	Set Screw for B-32	1 -	105827-0-01		B-79	Movable Presser Foot Stitch Tongue for 3-5mm	1 -	112472-0-01	
B-34	Set Screw for B-36	1 -	112192-0-01		B-80	Set Screw for B-79	1 -	112397-0-01	
B-35	Set Screw for B-36	1 -	100062-0-02		B-81	Needle Plate (C) for B958-06	1 -	117744-0-01	
B-36	Arm Pulley	1 -	112282-0-01		B-82	Main Feed Dog (C) for B958-06	1 -	117745-0-01	
B-37	Set Screw for B-38	1 -	013780-8-14		B-83	Sub Feed Dog (C) for B958-06	1 -	117746-0-01	
B-38	Driving Shaft Bushing-Right	1 -	112269-0-00		B-84	Stopper for B-61	1 -	140839-0-01	
B-39	Wick for B-38	1 -	112473-0-01		B-85	Set Screw for B-84	2 pcs.	105123-0-02	
B-40	Driving Shaft	1 -	112279-0-01		B-86	Felt for B-44	1 pce.	118855-0-00	
B-41	Set Screw for B-43	2 pcs.	110018-0-01		B-87	Packing for B-36	1 -	081010-0-70	
B-42	Set Screw for B-44	1 pce.	101706-0-01	112278-0-01	B-88	Needle Bar Bushing, Upper	1 -	146024-0-00	
B-43	Feed Eccentric	1 -	112280-0-01		B-89	Needle Bar Cap	1 -	146923-0-01	
B-44	Upper Knife Eccentric	1 -	112281-0-00		B-90	Set Screw for B-89	1 -	104651-0-01	
B-45	Needle Plate for B958-01 & 11	1 -	112441-0-01		B-91	Cap for B-89	1 -	112455-0-01	
B-46	Set Screw for B-45	2 pcs.	107231-0-01						
B-47	Driving Shaft Bushing Left	1 pce.	112270-0-00						

C



Ref. No.	Name of Parts	Q'ty	Parts No.	Assembly No.	Ref No	Name of Parts	Q'ty	Parts No.	Assembly No.
C-1	Set Screw for C-2	1 pce.	013780-8-14		C-42	Link Shaft for C-56	1 pce.	112372-0-01	
C-2	Feed Shaft Bushing, Left	1 *	112276-0-01		C-43	Wick for C-42	1 *	112373-0-01	
C-3	Set Screw for Feed Bar Guide	1 *	117139-0-01		C-46	Set Screw for C-53	1 *	112382-0-01	
C-4	Washer for Feed Bar Guide	1 *	118999-0-01		C-47	Upper Knife Presser Pin	1 *	112381-0-01	
C-5	Feed Bar Guide, Upper	1 *	112325-0-00		C-48	Set Screw for C-83	1 *	100242-0-03	
C-6	Feed Bar Guide, Lower	1 *	112326-0-00		C-49	Upper Knife Presser Spring	1 *	112386-0-01	
C-7	Feed Shaft	1 *	140792-0-01		C-51	Upper Knife Holder	1 *	112377-0-01	
C-8	Wick for C-7	1 *	112480-0-01		C-52	Upper Knife Holder Block	1 *	112380-0-01	
C-9	Indicator Plate Pin	2 pcs.	116231-0-00		C-53	Upper Knife	1 *	112376-0-01	
C-10	Indicator Plate for C-20	1 pce.	112313-0-01		C-54	Presser Plate for C-51	1 *	112378-0-01	
C-11	Oil Cap for C-7	2 pcs.	100251-0-01		C-55	Set Screw for C-54	2 pcs.	106202-0-01	
C-12	Set Screw for C-13	1 pce.	013780-8-14		C-56	Upper Knife Connecting Rod	1 pce.	112375-0-01	112459-0-01
C-13	Feed Shaft Bushing, Right	1 *	112275-0-01		C-57	Set Screw for C-56	2 pce.	144609-0-01	
C-14	Sub Feed Link	1 *	112316-0-01		C-58	Set Screw for C-41	1 pce.	100088-0-02	
C-15	Stud Screw for C-14	1 *	112314-0-01		C-59	Set Screw for C-60	1 *	100137-0-03	
C-16	Washer for C-14	1 *	112468-0-01		C-60	Main Feed Dog (A) for B958-01 & -11	1 *	112324-0-01	
C-17	Washer for C-14	1 *	112315-0-01		C-60A	Main Feed Dog (B) for B958-01 & -11	1 *	115961-0-01	
C-18	Nut for C-15	1 *	110161-0-01		C-61	Main Feed Bar	1 *	112323-0-00	112458-0-01
C-19	Stud Screw for C-14	1 *	112317-0-01		C-65	Sub Feed Bar	1 *	112318-0-00	
C-20	Sub Feed Lever	1 *	112312-0-00		C-62	Feed Bar Guide Block	1 *	112328-0-00	
C-21	Indicator Plate Pin	2 pcs.	116231-0-00		C-63	Collar for C-62	1 *	112329-0-01	
C-22	Indicator Plate for C-23	1 pce.	112321-0-01		C-64	Set Screw for C-63	2 pcs.	104649-0-01	
C-23	Main Feed Lever	1 *	112320-0-00		C-66	Sub Feed Dog (A) for B958-01 & -11	2 pce.	112319-0-01	
C-24	Set Screw for C-23	1 *	107428-0-02		C-66A	Sub Feed Dog (B) for B958-01 & -11	1 *	115962-0-01	
C-25	Main Feed Link	1 *	112322-0-01		C-67	Set Screw for C-66	1 *	100137-0-03	
C-26	Stud Screw for C-25	1 *	112314-0-01		C-68	Feed Shaft Block	1 *	112310-0-00	
C-27	Washer for C-25	1 *	112468-0-01		C-69	Lower Knife	1 *	112436-0-01	
C-28	Washer for C-25	1 *	112315-0-01		C-70	Set Screw for C-69	1 *	117516-0-01	
C-29	Nut for C-26	1 *	110161-0-01		C-71	Set Screw for C-72	1 *	101275-0-04	
C-30	Set Screw for C-31	1 *	107428-0-02		C-72	Lower Knife Holder Cover	1 *	112433-0-01	
C-31	Feed Lever	1 *	112306-0-00		C-73	Set Screw for C-74	1 *	100287-0-01	
C-32	Set Screw for C-31	1 *	107459-0-01		C-74	Lower Knife Holder	1 *	112430-0-01	
C-33	Feed Lever Shaft	1 *	112307-0-01		C-75	Needle Receiver	1 *	112440-0-01	
C-34	Rivet for C-33	1 *	112485-0-00		C-78	Stud Screw for C-74	1 *	112431-0-01	
C-35	Set Screw for C-33	1 *	102716-0-03		C-79	Lower Knife Holder Adjusting Screw	1 *	112432-0-01	
C-37	Feed Connecting Rod	1 *	112305-0-00	112457-0-01	C-80	Lower Knife Holder Plate	1 *	117515-0-01	
C-38	Set Screw for C-37	2 pcs.	142590-0-01		C-81	Wick for C-15 & C-26	2 pcs.	112474-0-01	
C-40	Set Screw for C-42	1 pce.	102850-0-01		C-82	Upper Knife Driving Lever	1 pce.	112371-0-01	
C-41	Upper Knife Driving Lever Shaft	1 *	112374-0-01		C-83	Upper Knife Holder Guide	1 *	148952-0-01	


D



Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.
D-1	Set Screw for D-2	1 pce.	105827-0-01	
D-2	Round Joint Guide	1 -	112285-0-01	
D-3	Over Looper Crank Felt	1 -	112410-0-01	
D-4	Over Looper Connecting Rod	1 -	116194-0-00	
D-5	Fastening Screw for D-4	4 pcs.	142590-0-01	116234-0-01
D-6	Adjusting Screw for D-7	2 -	100137-0-03	
D-7	Over Looper Crank	1 pce.	112409-0-00	
D-8	Set Screw for D-7	1 -	014770-6-22	
D-9	Round Joint for D-4	1 -	112412-0-01	
D-10	Fastening Screw for D-11	1 -	100541-0-01	
D-12	Looper Lever Shaft Thrust Washer	1 -	116199-0-01	116238-0-01
D-14	Looper Lever Shaft	1 -	116196-0-01	
D-11	Set Screw for D-13	1 -	100368-0-01	
D-13	Looper Lever Shaft Bushing Back	1 -	116197-0-00	
D-16	Fastening Screw for D-18	1 -	118876-0-01	
D-17	Fastening Screw for D-9	1 -	112287-0-01	
D-18	Looper Crank Joint	1 -	116195-0-01	
D-20	Fastening Screw for D-21	1 -	017751-4-13	
D-21	Over Looper Lever	1 -	116200-0-01	116235-0-01
D-23	Over Looper Link Shaft	1 -	116192-0-01	
D-22	Looper Lever Shaft Bushing Front	1 -	116198-0-01	
D-24	Felt for D-23	1 -	117430-0-01	
D-25	Under Looper Link	1 -	112416-0-01	
D-26	Felt for D-25	1 -	117429-0-01	
D-27	Under Looper Thread Take-up	1 -	112417-0-01	
D-28	Washer for D-27	1 -	112477-0-01	
D-29	Fastening Screw for D-27	1 -	110130-0-01	
D-30	Fastening Screw for D-31	1 -	100080-0-01	
D-31	Over Looper	1 -	112418-0-01	
D-32	Under Looper	1 -	112427-0-01	
D-33	Fastening Screw for D-32	1 -	112428-0-01	
D-34	Under Looper Lever	1 -	116188-0-01	
D-35	Over Looper Link Shaft	1 -	116192-0-01	
D-36	Under Looper Adjusting Lever	1 -	116191-0-01	116190-0-01
D-37	Fastening Screw for D-39	1 -	116267-0-01	
D-38	Felt for D-35	1 -	117430-0-01	
D-39	Under Looper Lever Shaft	1 -	116409-0-01	
D-40	Felt for D-39	1 -	112425-0-01	
D-41	Set Screw for D-39	1 -	013780-8-14	
D-42	Over Looper Thread Take-up	1 -	116193-0-01	
D-43	Fastening Screw for D-42	1 -	100185-0-03	


Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.
PARTS FOR TWO THREAD				
(B958-11)				
D-44	Needle Thread Guide Take-up for B-1	1 pce.	116528-0-01	
D-45	Needle Thread Guide Bracket for B-12	1 -	116527-0-01	
D-46	Spreader for D-31	1 -	116526-0-01	

E



Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.
E-1	Cap for Oil Inlet	1 pce.	112482-0-01		E-19	Cushion for E-20	1	112488-0-01	
E-2	Set Screw for E-4	2 pcs.	112359-0-01		E-20	Valve Stopper, Lower	1	112339-0-00	
E-3	Set Screw for E-29, E-4, E-8	1 pce.	112351-0-01		E-21	Pump Strainer Screw	1	112340-0-00	
E-4	Oil Tube No. 5 Assembly	1	140509-0-01		E-22	Presser Plate for E-21	1	112341-0-00	
E-5	Oil Tube Supporter	1	140506-0-01		E-23	Set Screw for E-22	2 pcs.	107244-0-01	
E-7	Packing for E-6	4 pcs.	112348-0-01		E-24	Presser Plate for E-26	1 pce.	112344-0-00	
E-8	Oil Tube No. 4 Assembly	1 pce.	140508-0-01		E-25	Set Screw for E-24	1	101531-0-04	
E-9	Set Screw for E-10	2 pcs.	142590-0-01		E-26	Oil Filter Net	1	118459-0-00	
E-10	Piston Rod for E-10	1 pce.	112331-0-00	112463-0-01	E-27	Oil Filter	1	118458-0-01	
E-11	Pin for E-10	1	112332-0-01		E-28	Set Screw for E-27	2 pcs.	105328-0-03	
E-12	Piston	1	112335-0-01		E-29	Oil Tube No. 1 Assembly	1 pce.	140507-0-01	
E-13	Piston Bush	1	112334-0-00		E-30	Set Screw for E-29	1	112364-0-01	
E-14	Cylinder	1	112333-0-00		E-34	Oil Tube Assembly for B-30	1	140509-0-01	
E-15	Set Screw for E-14	3 pcs.	105173-0-01		E-37	Packing for E-38	1	112353-0-01	
E-16	Valve Stopper, Upper	1 pce.	112338-0-01		E-38	Pipe Holder	1	118425-0-01	
E-17	Valve Bush	1	112337-0-01		E-39	Oil Filter Plate	4 pcs.	112369-0-01	
E-18	Valve	1	112336-0-01		E-32	Set Screw for E-34	1 pce.	112359-0-01	

Z



Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.	Ref. No.	Name of Parts	Qty	Parts No.	Assembly No.
Z-1	Accessory Box	1 pce.	110436-0-01		Z-18	Oiler	1	114483-0-01	
Z-2	Needle Bag	1	108962-0-01		● Z-19	Trimming Knife	1	118856-0-01	
Z-3	Needle DC×1	10 pcs.	112297		Z-20	Head Cover	1	144225-0-01	
Z-4	Wrench 10×12	1 pce.	107780-0-01		● Z-21	Chain	1	106812-0-01	
Z-5	Wrench 7×8	1	142205-0-01		Z-22	Foot Pedal	1	117437-0-01	
Z-6	Allen Wrench (3mm)	1	142721-0-01		Z-23	Foot Pedal Stopper	2 pcs.	116016-0-01	
● Z-7	Screw for Cushion Base	4 pcs.	031451-6-03		Z-24	Screw	2	001401-4-06	
Z-8	Cotton Stand (No. 3)	1 pce.	142973-0-01		Z-25	Nut	2	021400-1-06	
● Z-9	Screwdriver 2.6×70	1	105344-0-01		● Z-26	Tweezer	1 pce.	117466-0-00	
● Z-10	Screwdriver 5.5×75	1	102629-0-04						
Z-11	Screwdriver 5.5×200	1	101572-0-01						
● Z-12	Screw	1	105123-0-01						
● Z-13	Edge Hemming Ruler (A)	1	143552-0-01						
● Z-14	Edge Hemming Ruler (B)	1	112465-0-01	112464-0-01					
● Z-15	Adjusting Screw	1	112466-0-01						
● Z-16	Bolt	1	112398-0-01						
Z-17	Oil	1	145277-0-01						

Remark:

- ※ The parts with mark (·) are in accessory box.
 - ※ The following parts are enclosed in the accessory for our packing convenience.
- Ref. No. A-84, A-85, A-86